



Type, description	d <sub>1</sub> [mm]	l <sub>1</sub> [mm]	d <sub>A</sub> [mm]	D [mm]	
MAS-BT-ADB40-WE06-50-F	6	50	40	25	E01
MAS-BT-ADB40-WE06-50-V	6	50	40	25	E01
MAS-BT-ADB40-WE08-50-F	8	50	40	28	E02
MAS-BT-ADB40-WE08-50-V	8	50	40	28	E02
MAS-BT-ADB40-WE10-63-F	10	50	40	35	E03
MAS-BT-ADB40-WE10-63-V	10	50	40	35	E03
MAS-BT-ADB40-WE12-63-F	12	50	40	42	E04
MAS-BT-ADB40-WE12-63-V	12	50	40	42	E04
MAS-BT-ADB40-WE14-63-F	14	50	40	44	E04
MAS-BT-ADB40-WE14-63-V	14	50	40	44	E04
MAS-BT-AD40-WE16-35-F	16	35	40	48	E05
MAS-BT-AD40-WE16-35-V	16	35	40	48	E05
MAS-BT-ADB40-WE16-63-F	16	63	40	48	E06
MAS-BT-ADB40-WE16-63-V	16	63	40	48	E06
MAS-BT-ADB40-WE18-63-F	18	63	40	50	E06
MAS-BT-ADB40-WE18-63-V	18	63	40	50	E06
MAS-BT-AD40-WE20-35-F	20	35	40	50	E07
MAS-BT-AD40-WE20-35-V	20	35	40	50	E07
MAS-BT-ADB40-WE20-63-F	20	63	40	52	E08
MAS-BT-ADB40-WE20-63-V	20	63	40	52	E08
MAS-BT-AD40-WE25-40-F	25	40	40	50	E09
MAS-BT-AD40-WE25-40-V	25	40	40	50	E09
MAS-BT-ADB40-WE25-100-F	25	100	40	65	E10
MAS-BT-ADB40-WE25-100-V	25	100	40	65	E10
MAS-BT-ADB40-WE32-100-F	32	100	40	72	E11
MAS-BT-ADB40-WE32-100-V	32	100	40	72	E11
MAS-BT-ADB40-WE40-120-V	40	120	40	90	E12

E01	8395003300	6295000600
E02	8395003400	6295000800
E03	8395003500	6295001000
E04	8395003600	6295001200
E05		6295001600
E06	8395003700	6295001600
E07		6295002000
E08	8395027200	6295002000
E09		6295002500
E10	8395029000	6295002500
E11	8395029000	6295003200
E12		6295003200

